

ONLY TIGHTEN CHUCK NUT TO SECURELY HOLD CHALK DO NOT OVER TIGHTEN AS THIS MAY CAUSE CHALK TO BREAK