

Remove cap and select desired tool or screwdriver blade (if stored inside handle), return extra tools inside barrel, and replace cap. Insert specially designed keyed end, of screwdriver blade, into steel chuck. Insert tool into chuck (with screwdriver blades, turn blade while inserting into chuck until the keyed end slips into keyed slot in rear of chuck) and securely tighten chuck nut to firmly hold tool. Grip the Non-Slip Finger Grip surface on barrel to insert and remove screws or using tools. Do not hold onto the chuck nut while inserting or removing screws as it may loosen the chuck and screwdriver blade. When using in a forword and backward motions, such as filing, the handle assembly may be held on the chuck nut without loosening the chuck. Clip may be removed, if not needed, by removing cap and pushing clip offend of barrel.